



All Storage Vessels
held within this
boundary

Blue squares
indicate drains.

Storage Vessels Boundary

Drain Covers